

# **ES-400 RGY, ES-300 RGBV**



### Manual

Read carefully before using this device!

# **Bedienungsanleitung**Bitte lesen Sie diese Bedienungsanleitung, bevor Sie das Gerät in Betrieb nehmen!

Manual	1
Safety instructions	
Installation safety	2
INSTALLATION/OPERATION	2
Using the laser	
Control	3
DMX control	3
Maintenance / cleaning	4
Troubleshooting	
Technical specifications	
Please note	4
Hinweise zur Inbetriebnahme:	
Warnhinweise	5
Inbetriebnahme	6
Betriebsmodi/Steuerung	6
DMX Steuerung	6
Reinigung	7
Fehlerbehebung	7
Technische Daten	
Abschliessende Erklärung	7


#### **Checking Parts**

Please make sure the following parts are included:

- 1 x Laser projector
- 1 x Remote lock connector
- 1 x kev
- 1 x Power cable
- 1 x User manual

#### **Safety instructions**

If the device has been exposed to great temperature changes, do not switch it on immediately. Condensation water may damage your device. Leave the device switched off until it has reached room temperature.



Never leave this device running unattended and keep it away from children and unauthorized persons. Keep away from heaters and other heat sources. In order to safeguard sufficient ventilation, leave 50 cm of free space around the device.

Never direct the laser beam to people or animals.

CAUTION LASER DIODE: If you open the device for cleaning, always disconnect from mains!

# **HEALTH HAZARD!** Never look directly into the light source, as sensitive persons may suffer an epileptic shock!

These lasers are considered a definite eye hazard, particularly at the higher power levels, which WILL cause eye damage. So these laser series models supplied with a key switch to prevent unauthorized use, warning labels and aperture labels affixed to the laser.

#### **Installation safety**

Prior to installation and operation of the laser, the paths of the beams and effects should be considered, particularly with respect to how they will reach the audience. If direct audience scanning is desired, then the laser energy in the effects needs to be considered to decide if the effects are safe for direct viewing. Always ensure, that the maximum permissible exposure (MPE) is not exceeded in the area accesible to the public. So install the laser in such a way, that minimum distances and heights ensure the MPE is never exceeded in the public area. When audience scanning is performed, an operator has to be present. An easily accessible emergency switch has to be installed. When setting up the laser, make sure the laser is affixed firmly, to avoid vibrations.

## Warning labels on the device Laser radiation

Avoid exposure To the beam Laser class 3b

Caution of radiation If cover is removed Indoor use only

At front opening: Avoid exposure – laser radiation is emitted.

# I ASERBODATION WOOD DUCGUELTG BOAR OF ASSISTANCE DEVENUES: 1 2004 SECTION CAUTION OF SATURDING FOR CONTROL OF SATURDING FOR COME IS K-1950 VET 310-1210V C 330-340V SECTION SECTION SECTION OF SATURDING VETABLE K-1950 VET 310-1210V C 300-340V SECTION SECTI

Read manual before use Operation by qualified personal only Never direct laser Beam at people Never look directly into beam

#### INSTALLATION/OPERATION

Don't remove the warranty/serial number label - removal voids warranty

The operator has to make sure that laser radiation – for laser class 4 also reflected laser radiation – higher than the maximum permissible level is avoided by technical or organisational measures. (Especially with respect to the MPE, see above.)

Make sure to use the correct voltage. Use a power socket with earth/ground. **Don't use dimmer, RC,** or other **electronically switched** sockets. Whenever possible, don't use the laser together with large appliances, especially fog machines, on the same mains!

If the device is used in a flying installation, the mounting brackets and an appropriate safety-rope must be afixed.

In some countries, the operator must notify the accidence insurance and the authority for industrial safety, before operating a laser. For more information, contact the relevant authorities.

Please consider that unauthorized modifications on the device are strictly forbidden due to safety reasons! If this device will be operated in any way differently than described in this manual, the product may suffer damages and the guarantee becomes void. Furthermore, any other operation may lead to dangers like short-circuit, burns, electric shock, etc.



Keep surrounding dry and clean. This unit should be keep dry, do not use in the rain or damp and dusty environment, don't put liquid filled containers on the device. Projector should be put in a water-proof housing when operated outside.

Regularly open the device (see "cleaning" further down) to check for dust inside, or if fog fluid condenses in the housing (if so rearrange hazer and/or laser position).

Operating temperature is  $10\sim35$ °C. In a new installation, check after some 15-30 minutes whether the outlet air gets too warm. Regularly check the inside for dust deposits, especially around the fans. Let laser cool off 10minutes after 2 hours of operation, to ensure maximum lifetime for the diode.

Distance between laser aperture and projection screen should be not less than 1 meter.

Do not turn device on and immediately off again frequently.

Do not look into the laser beam directly, especially not with optical instruments.

Do not touch the device with wet hands.

When the laser diode becomes dim or broken, please contact your dealer.

When returning laser to dealer/manufacturer always use original packaging.

Maintenance should be performed every 15-day period. See "cleaning" further down.

To ensure maximum lifetime of the laser:

Don't overheat the laser:

- Always ensure good ventilation
- Don't have stage lights (especially moving heads) directed towards the laser
- Regularly clean the fans and the interior from dust
- In a new installation check the temperature after 30 minutes of operation

#### Keep the laser dry

- Make sure fog/hazer fluid doesn't condensate inside the laser fog has to be in front of the laser not inside
- A few days after (each new) installation, open the cover to check if fluids condensate inside
- If fluids condensate inside, reposition the laser or fogger/hazer

Turn the device off, when not used. The diode is on, when the device is on. Even if it is not lit. If the laser is equipped with a remote connector, connect an emergency switch to the Remote lock connector on the backside, the switch has to interrupt the connection between pins 1 and 2 to turn off the laser. If no emergency switch is used, insert the 9 pin dongle instead. If the laser has no remote lock, or the 9 pin dongle is used, use an emergency switch in the mains connection.

#### Using the laser

# Caution – use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Rigidly mount projector. Projector can be mounted in any position.

Make sure the correct voltage is used. Connect mains. Connect an emergency switch to the 9-pin connector on the backside (pins 1 and 2). If you do not wish to connect an emergency switch, connect the 9-pin plug instead. And use an emergency switch in the mains connection.

Turn the main switch to "1", depending on the mode selected (see below), laser light should come out of the opening on the front panel – be careful.

#### **Control**

1	Mains connector	3	Remote lock	5	DMX in/out
2	Main switch	4	DIP switch (see below)		

Setting Switch 10 to "on" puts the device into DMX mode. Connect a DMX controller to operate the laser. The following operating modes can be selected from the DIP switch on the backside of the device:

	<u> </u>
	<u> </u>
1	5

Dip switch	Mode	1,0,0,0,0,0,0,0,0,1	Automatic mode
0,0,0,0,0,0,0,0,1	Music active	x,x,x,x,x,x,x,x,0	DMX

"Music activ": patterns are changed/animated to the beat of the music. Sensitivity can be adjusted on the front panel (blue pot next to the microphone), the red LED flashes when music triggered.

"Automatic mode": patterns are changed automatically

"DMX": DMX512 Mode. Use the first 9 switches to select the address:

x x x x x x x x x x x x x 1 2 4 8 16 32 64 128 256

e.g. 1000 0000 01, DMX mode address 1 (1+0+0+0+0+0+0+0+0+0) 0010 0100 01, DMX mode address 36 (0+0+4+0+0+32+0+0+0)

#### DMX control

Chamal		
Channel	l Function	
Charine	i unction	

1	mode: 0-69 Laser off; 70-139 sound mode; 140-209 automatic mode,
	210-255 DMX mode
2	patterns / animations
3	strobe (with increasing speed)
4	Pointspeed
5	horizontal movement*
6	vertical movement*
7	zoom / size*, 010 no effect, 1192 increasing size, 93146 automatic
	small to large, 147200 dto large to small, 201255 small to large to
	small
8	Colour: 019, 2039, etc. single colours (3 for RGY, more for RGBV),
	above Patterns
9	Reset: above 200 (shortly)
10	Rotation X (width), 0150 static rotation, 151255 automatic rot.
11	Rotation Y (height), analogue to ch 9
12	Rotation Z, 0180 static rotation, 181217 automatic rotation clockwise,
	218255 automatic rotation counterclockwise

<sup>\*:</sup> not for all patterns.

#### Maintenance / cleaning

Always disconnect from the mains when the device is not in use or before cleaning it.

Open the device by removing the 4 screws of the top cover (2 upper screws at back/frontpanel). Remove any deposits of dust, especially at the fan. Check for condensed fog fluid inside, if so, clean and rearrange the position of laser and or hazer. Mirrors need cleaning, when a "halo" is noticeable around the beam, or an unusual high amount of diffuse light can be seen inside the device. Clean the mirrors with window cleaner and a paper towel. Never look directly into the light source. Always disconnect from the mains when the device is not in use or before cleaning it.

#### **Troubleshooting**

Problem	Possible cause
No function / fan not working	Check mains connection
Effects don't change to the beat of the music	Adjust sensitivity with the dial on the front.
	Check if device isn't in DMX or autom. mode
Problems with DMX control	Check DMX address selection
Device not working, but fan working	Turn device off for ca. 1 Minute.

#### **Technical specifications**

• Power supply: AC 85-250V,

• Ambient temperature: +10°C ... +35°C

• Power consumption: 40 W

• Operation modes: DMX 512, automatic, music mode

• Lasersources: aircooled DPSS laser (green), laser diode (red and blue/violet)

Optical power (at the laser):

ES-400 RGY: min. 300mW, max. 400mW, >80mW 532nm green, >220mW 655nm red ES-300 RGBV: min. 220mW, max. 300mW, >40mW 532nm green, >110mW 655nm red, >70mW

405nm blue/violet

• Beam: ca. 3mm/1mrad

• Laser class: 3b

• **Scanning system:** fast stepping motors 3-8kpps

Weight: 4.5 kg

• **Dimensions:** 23 x 27 x 16 cm (W x D x H)

• **Loudness:** <70db

#### Please note

This device has left our premises in absolutely perfect condition. In order to maintain this condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes written in this user manual. Laserworld cannot be made liable for damages caused by incorrect installations and unskilled operation! This manual is subject to change without notifice. Contact your local dealer for an update, or check our website <a href="https://www.laserworld.com">www.laserworld.com</a>. Errors and omissions expected. For service contact your dealer, or Laserworld. Only use Laserworld spare parts.

#### Lieferumfang

Bitte prüfen Sie, ob Sie wirklich alle Teile erhalten haben und ob diese von der Lieferung unbeschädigt sind. Zum Lieferumfang gehören:

- 1 x Laserprojektor
- 1 x Interlock Stecker
- 1 x Kaltgerätekabel zur Stromversorgung
- 1 x Bedienungsanleitung

#### **Hinweise zur Inbetriebnahme:**

- 1. Bitte stellen Sie sicher, dass die auf dem Gerät angegebene Spannung der entspricht, mit der Sie es betreiben wollen, bevor Sie den Laser in Betrieb nehmen.
- 2. Der Laser darf nur von technisch versiertem Fachpersonal gemäss den im jeweiligen Land geltenden Sicherheitsbestimmungen installiert werden. Insbesondere die darin geforderten Sicherheitsabstände zwischen Gerät und Publikum, bzw. maximal zulässige Bestrahlungswerte, müssen immer eingehalten werden.

# In bestimmten Ländern kann zusätzlich eine Abnahme durch ein technisches Überwachungsinstitut erforderlich sein!

- 3. Falls im Publikumsbereich gescannt wird muss ein Bediener anwesend sein.
- 4. Installieren Sie einen leicht zugänglichen Notaus Schalter.
- 5. Halten Sie bei der Installation einen Mindestabstand von 15 cm zur Wand und 1 m zu feuergefährlichen Materialien, Dekoration oder sonstigen Installationen ein.
- 6. Bringen Sie zur sicheren Installation ein Sicherheitsfangseil an. Das Fangseil sollte mindestens dem 10fachen Gewicht des Geräts standhalten können.
- 7. Schliessen Sie das Gerät nur an eine geerdete Steckdose an! Verwenden Sie immer ein Anschlusskabel mit Erdleiter und Schutzkontaktstecker! Schliessen Sie das Gerät nicht an Dimmer- oder andere elektronisch gesteuerten Steckdosen an. Vermeiden Sie den Betrieb mit grossen Verbrauchern (Scheinwerfer, Nebelmaschinen etc.) an derselben Leitung.
- 8. Sorgen Sie immer für eine ausreichende Belüftung. Insbesondere dürfen die Belüftungsöffnungen nicht verdeckt sein.
- 9. Netzstecker/Kaltgerätebuchse zugänglich halten.
- 10. Gerät fest montieren, um Vibrationen zu vermeiden.

#### Warnhinweise

- 1. Betreiben Sie das Gerät nur gemäss dieser Betriebsanleitung
- 2. Die Lüftungsöffnungen müssen beim Betrieb des Gehäuses frei sein
- 3. Benutzen Sie das Gerät nicht, wenn sichtbare Beschädigungen am Gehäuse, den Anschlussfeldern und vor allem an den Stromversorgungsbuchsen oder -kabel vorliegen.
- 4. Niemals direkt in den Strahl des austretenden Lasers blicken. Erblindungsgefahr!
- 5. Gerät nicht bei hoher Luftfeuchtigkeit, Regen oder in staubiger Umgebung betreiben. Vor Tropf-/Spritzwasser schützen, keine mit Flüssigkeit gefüllten Gefässe auf dem Gerät abstellen. Öffnen Sie das Gerät in regelmässigen Abständen, insbesondere nach Installation an einem neuen Platz, und überprüfen Sie, ob sich Nebelfluid im Inneren absetzt. Falls ja, reinigen Sie das Gerät, und ändern Sie die Position von Gerät und/oder Nebelmaschine. Überprüfen Sie ebenfalls, ob sich Staub, insbesondere im Bereich der Laser und Lüfter ansammelt. Falls ja, Gerät reinigen, sonst droht Gefahr des Überhitzens. Feuchtigkeit und Hitze können die Lebensdauer stark verkürzen, und führen zum Erlöschen der Garantie!
- 6. Stellen Sie sicher, dass das Gerät nicht zu heiss wird. Überprüfen Sie nach einer Installation an einem neuen Platz nach ca. 15-30 Minuten, ob die Abluft sehr warm wird. Stellen Sie sicher, dass das Gerät nicht dem Strahl von Scheinwerfern ausgesetzt werden (insbesondere bei beweglichen Scheinwerfern!), diese können in kurzer Zeit zur Überhitzung führen.
- 7. Stellen Sie sicher, dass der Netzstecker gezogen ist, wenn Sie am Gerät hantieren bzw. es installieren, oder es (zum Reinigen) öffnen.
- 8. Das Gerät nicht schnell hintereinander Ein- und Ausstecken, da dies die Lebensdauer der Laserdiode erheblich verkürzen kann!
- 9. Das Gerät sollte sich nach einer Stunde Dauerbetrieb für ca. 15 Minuten abkühlen.
- 10. Das Gerät bzw. das Stromkabel nie mit nassen Händen anfassen!
- 11. Sollten Störungen am Gerät oder der Diode auftreten, setzen Sie sich bitte mit Ihrem Händler in Verbindung

#### Warnhinweise am Gerät:

Laser Strahlung

Nicht dem Strahl aussetzen

Laserklasse 3b

Laserstrahlung bei geöffnetem Gehäuse



Nur in geschlossenen Räumen betreiben

Bestrahlung vermeiden - Austritt von Laserstrahlung.

Vor Benutzung Anleitung durchlesen

Betrieb nur durch qualifiziertes Personal

Laserstrahl nie auf Menschen richten

Nie in den Laserstrahl schauen

#### Inbetriebnahme

Am Strahlaustritt:

Gerät sicher stellen/befestigen. Gerät kann in jeder Lage betrieben werden. Verbinden Sie das Gerät mit dem Stromnetz, schliessen Sie einen Not Aus Schalter an den remote lock Anschluss auf der Rückseite an (der Schalter muss die Verbindung zwischen Pin 1 und 2 trenne, um den

Laser abzuschalten), falls kein Not Aus am remote lock angeschlossen wird, mit beigefügtem Blindstecker kurzschliessen und Not Aus in der Netzspannungszufuhr anbringen. Stellen Sie den Netzschalter auf ".1" Der Laserstrahl tritt nun aus der vorderen Öffnung - Vorsicht.

# In DMX Out

#### **Betriebsmodi/Steuerung**

1	Netzanschluss	3	Remote lock	5	DMX in/out
2	Hauptschalter	4	DIP Schalter (s.U.)		

Am DIP Schalter an der Gehäuserückseite können Sie folgende Betriebsmodi eistellen:

Dip switch	Modus	1,0,0,0,0,0,0,0,1	Automatisch
0,0,0,0,0,0,0,0,0,1	Musiksteuerung	x,x,x,x,x,x,x,x,0	DMX

**<sup>&</sup>quot;Musiksteuerung":** Muster werde im Rhythmus geädert/animiert. Empfindlichkeit kann an der Vorderseite (blaues Poti) eingestellt werden, die rote Kontrol LED zeigt an, wenn die Steuerung anspricht.

"DMX": DMX512 Modus-. Adresseinstellung über die ersten 9 Schalter:

x x x x x x x x x x x 1 2 4 8 16 32 64 128 256

Z.B. 1000 0000 01, DMX Modus Adresse 1 (1+0+0+0+0+0+0+0+0+0) 0010 0100 01, DMX Modus Adresse 36 (0+0+4+0+0+32+0+0+0)

#### **DMX Steuerung**

Kanal	Funktion
1	Modus: 0-69 Laser aus; 70-139, Musik Modus 140-209 Automatik Modus; 210-255 DMX Modus
2	Muster
3	Strobe/Blinken (mit zunehmender Geschwindigkeit)
4	Teilweises Zeichnen
5	Horizontale Bewegung*
6	Vetikale Bewegung*
7	Grösse/Zoom, 010 kein Effekt, 1192 zunehmende Grösse, 93146 automatischer Wechsel klein nach gross, 147200 dto. gross nach klein, 201255 dto. gross/klein/gross*
8	Farbe: 019, 2039 Einzelfarben (3 für RGY, mehr bei RGBV). Danach Farbmuster
9	Reset: kurz über 200 gehen
10	Rotation X (Breite), 0150 statisch, 151255 automatisch (zunehmende Geschwindigkeit)
11	Rotation Y (Höhe), analog zu Kanal 9
12	Rotation Z, 0180 statisch, 181217 automatisch im Uhzeigersinn, 218255 automatisch entgegen

<sup>\*</sup> nicht bei allen Mustern

<sup>&</sup>quot;Automatisch": Muster werden automatisch durchgewechselt.

#### Reinigung

Reinigen Sie das Gerät regelmässig, um seine lange Lebensdauer zu erhalten. Trennen Sie dazu das Gerät unbedingt zuvor vom Netz (Netzstecker ziehen)! Schauen Sie niemals direkt in den Laserstrahl! Zum öffnen entfernen Sie 4 Schrauben des Deckels (je 2 Front-/Rückplatte oben). Entfernen Sie eventuelle Staubansammlungen, insbesondere im Bereich der Lüfter und Laser. Sollten sich Spuren von Nebelfluid absetzen, Gerät reinigen und Position von Gerät und/oder Nebelmaschine ändern. Verwenden Sie zur Reinigung klares Leitungswasser, oder Alkohol und ein weiches Tuch. Für eine optimale Lichtausbeute sollten die Spiegel sauber und ohne Kratzer sein. Bereits kleinste Kratzer können die Geräteleistung erheblich beeinträchtigen! Sie sollten die Spiegel reinigen, wenn ein deutlicher "Halo" um den Laserstrahl zu erkennen ist, oder ungewöhnlich viel Streulicht im Gerät zu sehen ist. Spiegel Idealerweise mit Aceton und Linsenpapier, sonst mit Fensterreiniger und Papierwischtuch, reinigen. Immer in eine Richtung wischen um die Auswirkung möglicher Kratzer zu minimieren.

**Fehlerbehebung** 

i cilici beliebulig	
Fehlfunktion	Behebung / Ursache
Keine Funktion / kein Lüftergeräusch	Stromversorgung/Sicherung überprüfen
Die Lasereffekte wechseln nicht in Abhängigkeit von der Musik	Erhöhen Sie die Lautstärke der Musik oder die Empfindlichkeit mit Hilfe des Reglers an der Rückseite des Lasers Überprüfen Sie, dass sich das Gerät nicht im DMX- oder Automatikmodus befindet
Es treten Probleme bei der DMX-Steuerung auf	Überprüfen Sie die korrekte Einstellung der Adressen
Keine Funktion aber Lüftergeräusch vorhanden	Gerät ausschalten und nach ca. 1 Minute wieder einschalten

#### **Technische Daten**

**Laserquellen:** luftgekühlter DPSS Laser (grün), Diodenlaser (rot, blau/violett)

Leistung (am Laser):

ES-400 RGY: min. 300mW, max. 400mW, >80mW 532nm grün, >220mW 655nm rot ES-300 RGBV: min. 220mW, max. 300mW, >40mW 532nm grün, >110mW 655nm rot, >70mW 405nm blau/violett

• Laserklasse: 3b

Betriebsmodi: DMX 512, Automatik Modus, Musik Modus
 Scannersystem: schnelle Schrittmotoren 3-8 kPPS

• **DMX 512:** 12 Kanäle

Strahldaten: ca. 3mm/1mradStromversorgung: 85~250V AC

Stromaufnahme: 40W

Abmessungen: 230 x 270 x 160 mm (B x T x H)

• **Gewicht:** 4,5 kg

• Betriebstemperatur: 10°-35°C

Lautstärke: <70db</li>

#### Technische Änderungen vorbehalten!

#### Abschliessende Erklärung

Sowohl Produkt als auch Verpackung sind beim Verlassen der Fabrik einwandfrei.

Der Benutzer des Geräts muss die lokalen Sicherheitsbestimmungen und die Warnhinweise in der Betriebsanleitung beachten. Schäden, die durch unsachgemässe Handhabung entstehen, unterliegen nicht dem Einflussbereich der Herstellers und Händlers. Somit wird keine Haftung bzw. Gewährleistung übernommen. Sollten Änderungen an dieser Bedienungsanleitung vorgenommen werden, können wir Sie darüber nicht in Kenntnis setzen. Bitte kontaktieren Sie für Fragen Ihren Händler.

Für Service wenden Sie sich bitte an Ihren Händler oder an Laserworld. Verwenden Sie nur Laserworld Ersatzteile

Änderungen vorbehalten! Aufgrund der Datenmenge sind Fehler nicht auszuschliessen

#### Laserworld (Switzerland) AG

Kreuzlingerstrasse 5 8574 Lengwil-Oberhofen SWITZERLAND



Authorized person:

Supervisory board Mr Martin Werner

place of business: 8574 Lengwil / SWITZERLAND

company number: CH-440.3.020.548-6 Commercial Registry Kanton Thurgau

www.laserworld.com info@laserworld.com

representative according to EMVG:

Cleantech Europe GmbH

Managing Director: Thomas Schulze

Fürkhofstr. 5

81927 München / DE